


SET UP GUIDE FOR ARCH FLAG - 2,4 m & 3,2 m height.



Watch set-up video
for easy assembling


Use link or QR-code:

<https://bannerbow.com/videos/>



Note:
Outdoor use requires using
Guy Ropes and anchors.

CONTENT



Packaged by:

BANNERBOW®
DESIGNING PORTABLE SPACE

CONTACT INFORMATION

info@bannerbow.com
www.bannerbow.com

Address:
Rinmansgatan 18
633 46 Eskilstuna
Sweden



COPYRIGHT BANNERBOW®